

4M PREMIUM PS4® PLAY &CHARGE CABLE



CONTENTS:

x1 Premium Play & Charge Cable

SETUP:

1. To charge your DUALSHOCK®4 wireless controller first insert the USB A jack into an available USB port on your PS4®.
2. Now insert the Micro-USB end of the 4M Premium Play & Charge Cable into your DUALSHOCK®4 wireless controller – when charging begins the light bar will illuminate orange.
3. Due to the long length of the charging cable you can now comfortably play whilst you are charging your DUALSHOCK®4 wireless controller.

TECHNICAL SUPPORT

If you encounter a problem with your product, please go to <http://www.numskull.co.uk> and click Technical Support. From there you will be able to access “Frequently Asked Questions” section, and contact details.

Alternatively you can contact us at:

Email: hello@numskull.com

International Telephone: +441707 502280

WARRANTY INFORMATION

Worldwide, Rubber Road Ltd warrants to the consumer that all Numskull products will be free from material defects and manufacturing flaws for a period of one (1) year from the original date of purchase. Should the product appear to be

defective during the warranty period, immediately contact Technical Support, who will indicate the procedure to follow. If the defect is confirmed, the product must be returned to its place of purchase (or any other location indicated by Technical Support).

Within the context of this warranty, the consumer's defective product will, at Technical Supports option, be either repaired or replaced. Where authorized by applicable law, the full liability of Rubber Road and its subsidiaries (including for indirect damages) is limited to the repair or replacement of the Numskull product. The consumer's legal rights with respect to legislation applicable to the sale of consumer goods are not affected by this warranty.

This warranty shall not apply: (1) if the product has been modified, opened, altered or has suffered damage as a result of inappropriate or abusive use, negligence, an accident, normal wear, or any other cause not related to a material defect or manufacturing flaw; (2) in the event of failure to comply with the instructions provided by Technical Support; (3) to software not published by Rubber Road, said software being subject to a specific warrant provided by it's publisher.

ENVIRONMENTAL PROTECTION RECOMMENDATION



At the end of its working life, this product should not be disposed of with standard household waste, but rather dropped off at a collection point for the disposal of Waste Electrical and Electronic Equipment (WEEE) for recycling. This is confirmed by the symbol found on the product, user manual or packaging. Depending on their characteristics, the materials may be recycled. Through recycling and other forms of processing Waste Electrical and Electronic Equipment, you can make a significant contribution towards helping to protect the environment. Please contact your local authorities for information on the collection point nearest you.

COPYRIGHT



, "PlayStation" and "DUALSHOCK" are registered trademarks of Sony Interactive Entertainment Inc. All rights reserved. Licensed for sale in Europe, Africa, Middle East, Russia, India and Oceania and for use exclusively with PlayStation®4. Manufactured by Rubber Road Ltd. United Kingdom, AL7 2AD (Rubberroad.co.uk)

Made in China

©Rubber Road – www.rubberroad.co.uk

Numskull – www.numskull.com

